

INSTRUCTIONS FOR FLOODLIGHT



IMPORTANT


Read these instructions fully before using the Floodlight. Retain these instructions for future reference.

Main construction Data


Model	Rated Power	IP	Dimensions (MM)
B1458-N	50	65	235*173*44

General safety instructions

- Never look directly into the LED light source. The light emitted can contain the colour blue.
- To clean: Ensure that the floodlight is disconnected from the mains and cannot be unintentionally reconnected.
- Place only upon level and stable surfaces.
- Do not use in rooms in which there is a danger of explosion.
- Do not place in water or other liquids.
- Never operate with wet hands.
- Never attempt to repair this unit yourself. Repairs should only be carried out by the manufacturer or their authorised service personnel.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- The distance between the item and the objects must be more than 1 M.



- When the front glass was broken, the light must be disconnected the power supply and forbidden to further use.
- Replace every broken front glass by an original front glass!



Installation

Installation may only be carried out by trained professionals according to the applicable installation regulations. Contact a licensed electrician. **ATTENTION!!**

Before installation, the power supply must be disconnected and locked out.

- Turn OFF power supply, ensure all required equipment and tools are present.
- Connect the pre-wired cable to the electrical supply, observing the correct polarity.


LIVE = BROWN

EARTH = GREEN/YELLOW

NEUTRAL = BLUE

- Check connections and fixing.
- Turn on Power and operate the floodlight as required.
- Setting the Floodlight Direction

The Remote control



Cleaning

Before cleaning the LED floodlight, disconnect the power cable and allow the floodlight to cool down sufficiently. Clean with a dry or slightly moist, clean, lint-free cloth and a mild detergent if required. Do not use cleaners that contain abrasives or solvents.

Maintenance

- Check the plug, power cable, and housing of the LED floodlight for damage before each use. If the lens is damaged it must be replaced immediately.
- Clean any dirt from the housing or the lens immediately, since it could cause overheating.



Correct Disposal of this product

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.